



January 2, 2015

2001 Co. General EPDM Installation Requirements

- Seams must be clean and dry and completed per 2001 Co. seaming requirements. (refer to Zip Tape Instructions)
- Ponding water requires seams to be stripped in with ZIPFLASH (cured cover tape), six inch (6") minimum.
- In cold weather applications (less than 50°F) never install primer and seam tape after the temperature has started to fall, as the adhesives will not work properly.