



January 2, 2015

Accelerated Forced Air Roof Drying – Introduction

Installing the 2001 Co. Wind Vented System will dry out a wet roof. Permeating the wet roof prior to installing the new 2001 Co. System will speed up the drying process; however, for accelerated drying, the 2001 Co. has a patented technique that can be used with our 2001 Co. Wind Vented System or it can be adapted to a conventional roof system and the original membrane may be salvaged. In some cases it may be advantageous to install our accelerated drying system on a conventional roof and coat the existing membrane with a quality roof coating.