

2001 Company Seam Tape Instructions



1. Overlap the top membrane 3 1/2' over the bottom membrane. Clean the top of the lower membrane and the bottom of the upper membrane with Membrane Cleaner.



2. Here we can see that the seam tape has already been affixed to the bottom membrane and that the top membrane is being applied a layer of Primer after cleaning.



3. The folded seam of the upper membrane is ready to be folded over against the seam tape.



4. Note that the seam tape's backing paper is being removed at an angle. The sticky side of the seam tape will now stick to the membrane onto the layer of primer.

2001 Company Seam Tape Instructions



A close up of the angle that the paper backing is supposed to be pulled at.



As one man pulls the paper backing, the other one presses down on the top membrane affixing it to the bottom sheet.



Another view of the top membrane folded over and being cleaned while the seam tape has already been put down.



Another view of the backing paper being pulled from the seam tape.